

Z-TRAY

Vented Sintering Tray and Cover

Z-Tray Vented Sintering Trays provide a convenient and protective method of sintering. Z-Tray is perfect for sintering crowns, bridges, inlays, onlays, and veneers. This dense, round, ceramic tray provides nearly complete protection from undesired gas vapor condensation on your restoration. Z-Tray used with the sintering cover prevents occasional zirconia discoloring that may otherwise occur due to the heating elements. Having a max service temperature of 1700 degrees Celsius, Z-Tray Vented Sintering Tray maintains good thermal shock and can withstand both a fast heating rate for zirconia and a slow heating rate for long-span bridgework or complex cases. For best results, use with zirconia sintering beads.

Advantages:

- Easily used for fast and slow heating rates
- Contamination free firing results
- Good thermal shock
- Resistant to cracking
- Withstanding up to 1700 degrees Celsius

Size: 75mm tray with cover

Item #142

Suggested Retail Price \$47.50

Size: 100mm tray with cover

Item #144

Suggested Retail Price \$55.95

